

# smorphi<sup>2</sup>

transforming learning with  
transformer robots

assembly & info

# ( contents )


<b>PART LIST</b>	-----	( 02 )
<b>BASIC ASSEMBLY TIPS</b>	-----	( 03 )
<b>SMORPHI ASSEMBLY</b>		
<b>A MECHANICAL</b>	-----	( 05 )
<b>B ELECTRONIC</b>	-----	( 16 )
<b>APP</b>	-----	( 29 )
<b>FURTHER EXPLORATION</b>	-----	( 32 )

( part list )

4 x Acrylic Base Plate



2 x Aluminium Base Plate



4 x Base Skirt Panel A



4 x Base Skirt Panel B



4 x Mecanum Wheel (Right)



4 x Mecanum Wheel (Left)



8 x Mecanum Motor



8 x Motor Shaft Sleeve



8 x Motor Mount



2 x Solenoid



2 x Solenoid Latch Mount



2 x Solenoid Latch Guide



All colors of parts are represented accurately here.  
In the assembly steps, colors of some parts will be changed for diagram clarity.

2 x Solenoid Catch



2 x Hinge Mount



1 x Hinge Mechanism



1 x Battery



2 x Battery bracket



1 x Masterboard (ESP32)



2 x Slaveboard



1 x Sound Sensor



1 x Temperature Sensor



4 x IR Sensor



6 x Sensor Lock



12 x Hex F-F M3 Nylon 10mm



16 x Hex M-F M3 Nylon 45mm



100 x Cap Screw M3x5



30 x Cap Screw M3x25



5 x Countersunk Screw M4x8



2 x Wing Screw M3x5




1 x USB Cable




6 x 4-pin Connector



2 x 8-pin Connector



1 x Battery Charger




1 x Ceramic Screwdriver CD-25




1 x HEX Key 1.5mm




( basic assembly tips )










## A 1 (motor sub-assembly)

-  Motor Mount (8)
-  Motor Shaft Sleeve (8)
-  M3x22 (24)
-  DC Motor (8)
-  Left Mecanum Wheel (4)
-  Right Mecanum Wheel (4)




- ✖ 2 ways to differentiate between Left and Right Mecanum wheel
- Look for L or R on the inside of the wheel
  - Left/Right wheel roller points up to Left/Right











A2 (base module sub-assembly)

- AI Base Plate (2)
- Hex M-F M3 45mm (8)
- M3x5 (16)
- Left Wheel SA (4)  
from A.1
- Right Wheel SA (4)  
from A.1




⚠ Make sure that the numbers are facing the right way up as shown in the plan view above.



⚠ Before attaching each wheel, check that the wheel is of the correct orientation for each numbered slot.



x2 =




- Base Skirt Panel A (4)
- Base Skirt Panel B (4)
- M3 x 5 (12)





x 2

=



### A3 (solenoid latch sub-assembly)


- Solenoid latch (2)
- Solenoid latch mount (2)
- Solenoid latch guide (2)
- M3 x 5 (4)






**A 4** (module 1 mechanical sub-assembly)

- Hinge mount (1)
- Solenoid catch (1)
- Solenoid latch SA (1)  
*from A.3*
- Base Module SA (1)  
*from A.2*
- M3 x 5 (5)









⚠ Pay attention to the numbers and their positions in relation to the parts being attached.



⚠ Check that the parts have been attached in the right location, in relation to the numbers.

**A5** (module 2 mechanical sub-assembly)

- Hinge mount (1)
- Solenoid catch (1)
- Solenoid latch SA (1)  
*from A.3*
- Battery bracket (2)
- Li-ion Battery (1)
- Base Module SA (1)  
*from A.2*
- M3 x 5 (6)
- Wing Screw M3 x 5 (1)








✖ Pay attention to the numbers and their positions in relation to the parts being attached.

✖ Check that the parts have been attached in the right location.



**A6** (full mechanical assembly)

- Module 1 (1)  
from A.4
- Module 2 (1)  
from A.5
- Hinge mechanism (1)
- M4 x 8 (4)




✖ Pay attention to the numbers and their orientation when attaching the modules together.

✖ Check all the positions of solenoids, solenoid catches, hinge mounts before proceeding to section B.



**A** mechanical assembly completed

## B1 (e-tray sub-assembly)






✘ Make sure that you are attaching the slaveboards and not the masterboard.


✘ How to differentiate between masterboard and slaveboards:  
- Masterboard has a special switch




## B2 (e-tray onto mechanical assembly)




✘ Orientate e-tray SA and base module as shown on the right.  
Motor 1 connector on e-tray should be on top of Motor 1 of base module.  
Same goes for Motor 2, 3 and 4.








## B3 (all module motor cable connection)





✖ Make sure that Motor 1 is connected to Motor 1 connector on Slaveboard; the same goes for Motor 2, 3 and 4.

✖ Motor cable connection is the same for both modules






B 4 (module 1 solenoid cable connection)





✖ Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.




Module 1  
Solenoid Connection

Opening to pass wire through

B 5 (module 2 solenoid cable connection)



✖ Make sure to connect the solenoid to the labelled solenoid connector exactly as in the diagram below.





Module 2  
Solenoid Connection

Opening to pass wire through


B6 (inter-module cable connection)

- 8-pin connectors (1)
- full assembly (1)  
from B.5




B7 (address selection)

- full assembly (1)  
from B.6
- ceramic screwdriver (1)




✖ Use the ceramic screwdriver to adjust the rotary switch and select the address for all 2 modules.  
Module 1: Address 0, Module 2: Address 1







B8 (masterboard e-tray sub-assembly)

- Acrylic base plate (1)
- Masterboard (ESP32) (1)
- Hex F-F M3 10mm (4)
- M3 x 5 (8)




- Make sure that you are attaching the masterboard and not the slaveboards.
- How to differentiate between masterboard and slaveboards:
  - Masterboard has a special switch




B9 (masterboard e-tray onto main assembly)


- masterboard e-tray SA (1)  
from B.8
- full mechanical SA (1)  
from B.6
- 8-pin connector (1)
- M3 x 5 (4)



- Align the header to slaveboard connector on the masterboard to face the side connecting Motor 1 and 4



! "DO NOT PLUG-IN / UNPLUG THE CONNECTOR CABLES WHILE THE POWER SUPPLY IS ACTIVELY PROVIDED (EITHER THROUGH BATTERY/ USB)"






Opening to pass wire through




B 10 (attach acrylic covers & connect battery to masterboard)

- Acrylic base plate (1)
- full mechanical SA (1)
- M3 x 5 (4)



B 11 (check connection)




After checking that the lights are turned on, press on the enable button to activate the robot

B

electronic assembly completed

smorphi is ready!

next step: connect with app




( app )

1. App Download.



Not all devices are compatible now.  
See the table below to check if your device is compatible with the Smorphi app.

Smorphi App Information	
Available Platforms	( Android )
Download from	( Google Play )
App Icon & Name	 smorphi
System Requirements OS Requirements	( Android 6+ Bluetooth 4.0+ )

PAIR WITH YOUR NEW SMORPHI

PAIR WITH YOUR OLD SMORPHI

1

Tap on this side for first time pairing to Smorphi

DISCOVER BLUETOOTH DEVICES TO PAIR WITH

7B:7A:22:05:50:62

5D:9A:CD:C7:D8:8C  
smorphi  
4C:75:25:55:C7:32

50:51:A9:74:FA:29

5D:9A:CD:C9:92

88:78:73:73:71:4C

78:85:F4:F3:A8:68

NEXT

2 tap to search for bluetooth devices

3 select smorphi from the list

4

Smorphi App

smorphi  
4C:75:25:55:C7:32


5

Tap on paired smorphi to connect

Smorphi App

Bluetooth icons and refresh buttons

### 3. Smorphi controls dashboard guide.



✕ For tutorial to Smorphi activities and exercises, please refer to the online class exercises by following the link below:  
<https://github.com/WefaaRobotics/Smorphi/wiki/>




## ( sensors )



**sound sensor** (x2)

Sound sensor measures volume of sound. Onboard potentiometer\* can be used to tune the range of sensing. Possible applications: sound-triggered shape transformation or sound-triggered locomotion.



**IR sensor** (x4)

IR sensors comes with 2 different modes, toggled by the switch onboard the sensor itself. One IR is front-facing and can be used to detect obstacles ahead. The other IR faces the ground and can be used for path tracking.

✕ For sensor related activities and implementation, please refer to the online class exercises by following the link below:  
<https://github.com/WefaaRobotics/Smorphi/wiki/Robot-Exercises>





**temperature sensor** (x1)


Temperature sensor measures surrounding temperature, with a range of -55°C to 125°C.

\* Tutorial on how to operate the potentiometer can be found by following the link below:  
<https://github.com/WefaaRobotics/Smorphi/wiki/Exercise-6>

## ( sound/IR sensor wiring )




✕ Sound/IR sensor can be connected to any of the 6 sensor ports on the slaveboard (top) or any of the 4 sensor ports on the masterboard (bottom).



Module 1 or 2

Connect to masterboard or slaveboard


## ( temperature sensor wiring )



✖ Temperature sensors can only be connected to any of the 4 sensor ports on the masterboard.

Opening to pass wire through


## ( sensor position 1 )



✖ Sensors can be secured to the robot using the sensor lock provided




## ( sensor position 2 )



✖ Sensors can also be attached at the skirt panel of the robot


## ( connect to laptop )



✖ Plug in the USB-C cable as shown above to connect the masterboard to the computer. It allows us to upload our code from our computer onto the masterboard.



# ( charging )



✕ When battery is charging, an orange light will be shown on the charger. Once battery is fully charged, a green light will be shown

